

Install vault
Install ground rod
Install 1 empty conduit
from pole to vault.
Bring 2 - .625 cic to the pole
and leave 30' coil

Install 14" ped
Install ground rod
Bury 1 empty conduit
from pole to ped

Install 9" ped
One .625 cic from pole
to the 9" ped.
One .625 cic from pole
straight to the 14" ped.
One empty conduit from pole
straight to the vault.

One .625 cic
One empty conduit

Riser up pole
Leave 30' coil
Pole is in cement sidewalk

Contractor Map
Derrick Abraham
320-980-3523
MN15019
724 E Centre St
Royalton

