



this pole is not here
 this pole & pole to north show same barcode
 all cust are fed from tx pole

st # 13
 replace pole
 install oh span guy

st # 17
 install de pole 2
 risers & 3 phase prim ug
 3 phase is bored in pipe

st # 11
 replace pole

st # 12
 replace tx pole, add 10 kva
 tx to close in bank

st # 14
 install de pole
 & anchor

st # 15
 install slack span
 add 10 kva to close in tx

st # 16
 install sec ug to serve ext cust
 remove 2 poles oh prim
 tx bank

st # 18
 move existing oh
 prim to new pole