

INSTALL COVERUPS

STN 1 (M5521882)

SHIFT WIRES TO
POLE 15FT NORTH.
-7FT DGA TO NORTH.

KEEP POLE
*After Culvert Install,
Transfer Wires Back.*

STN 2 (M5521881)

LEAN POLE TO NORTH

PZG-2

298FT
PZG-2

PZG-2

291FT

MORRISON

290FT
PZG-2

PZG-2

M5521883

M5521882

M5521881

M5521880

M5521879

Cnty Rd 46)

46

Work Order Number: #5182975

Designed By: **Andrew Kotz** 320-360-9246



This map may not be prepared to scale. Under no circumstances should this map ever be used to determine the location of the facilities depicted. Minnesota Power/Allete disclaims all responsibility for any such use and shall not be liable for any indirect, consequential or other damages, however caused.