



RX02

RX01

NATURE RD

W CENTRE ST

S CHESTNUT ST

N 3RD ST

N ASPEN ST

N 2ND ST

N REDWOOD ST

N REDWOOD ST

TRAILER PARK U

TRAILER PARK U

Install 1 - 1.25 ducts.

STOP HERE

STOP FLOW

Leave 50' coil in vault
Install 24ct fiber
Install fiber markers

Contractor Redline Map
Derrick Abraham
320-980-3523
Nature Rd
Royalton
MN03118
Instructions: Install vault and ground rod
Install 24ct fiber and install 1 - 1.25 ducts
from vault to vault.

Dig back 50' of tail swing into
new vault at this location.
Leave 50' tails
Install ground rod and
fiber markers